

PHILIPS



50310/**/**

50312/**/**

50313/**/**

50314/**/**

50310/**/**



50312/**/**



50313/**/**



50314/**/**






User manual
Benutzerhandbuch
Notice d'emploi
Manual de usuario
Manual do usuário
Manuale d'uso
Gebruiksaanwijzing

Incl.













A










B






Excl.











Signify
I.B.R.S. / C.C.R.I. Numéro 10461
5600 VB Eindhoven,
the Netherlands
00800-74454775

© 2020 Signify Holding
All rights reserved

www.philips.com/lighting

4404 029 01313
Last update: 09/2020