





RS071B



	9290033225 , 9290033226 , 9290033227 , 9290033228
Electrical characteristic	
I _{max} (A)	1.4
T _{ref} (ms)	0.2
MCB	Luminaires Max.(pcs)
Type B-10A	150
Type B-16A	240
Type C-10A	191
Type C-16A	306



- 01 Please read this manual before you start to install the luminaire.
- 02 The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations of the national requirements.
- 03 Switch OFF the power supply before the installation or maintenance to avoid electrical shock.
- 04 The luminaire must not be used or stored in corrosive environment where hazardous materials such as Sulphur, Chlorine, Phthalates, etc., are present.